

NOTICE DE SECURITE

• Conservez cette notice tant que vous utilisez l'appareil.

SAFETY NOTE

• Keep this note as long as you use the device.

INSTRUCCIONES DE SEGURIDAD

• Conserve esta reseña mientras utiliza el aparato.


SICHERHEITSHINWEIS

• Bewahren Sie diese Notiz so lange auf, wie Sie das Gerät verwenden.

NOTA DI SICUREZZA


• Conservare questa nota finché si utilizza il dispositivo.

1




Coupez le courant
Turn off the power
Apaga el poder
Spegni il potere
Schalten Sie das Gerät aus


2



3



4



5

